KETRON SD 1000 Sould List for malletKAT /vibeKAT

U01	**Grand Piano**	U33	**Dyna GTR**	U65	**Drama**	U97	**Clarinet**		
U02	**Layer Piano**	U34	**Strato FX**	U66	**Odessey**	U98	**Pan Flute**		**VIBEKAT**
U03	**Latin Piano**	U35	**12 String**	U67	**Solist**	U99	**Sawtooth**		**SOUND GROUPS**
U04	**Piano String**	U36	**Western**	U68	**Glockpad**	U100	**Cliff Lead**	**GROUP**	
U05	**Jingle**	U37	**Wha Guitar**	U69	**Classic**	U101	**Sound Track**	**1**	**Keys 1-21**
U06	**Para Harp**	U38	**Hawaian**	U70	**F Musette**	U102	**Star Theme**	**2**	**Guitars 22-44**
U07	**Harp**	U39	**Django**	U71	**Cassotto**	U103	**Horn Cresc**	**3**	**Basses 45-57**
U08	**Hot Organ**	U40	**Classic FX**	U72	**Daa**	U104	**Slow Violin**	**4**	**Solos 58-67**
U09	**Deep Jazz**	U41	**Nylon**	U73	**Daah Doos**	U105	**Staccato**	**5**	**Mixed 68-75**
U10	**Percussive**	U42	**Steel**	U74	**Laah**	U106	**Quartet**	**6**	**Acoustics 76-84**
U11	**FM Thin**	U43	**Muted**	U75	**Voices**	U107	**OctaStrings**	**7**	**Synths 85-93**
U12	**RX Operator**	U44	**Lute**	U76	**Trumpet**	U108	**Slow Arco**	**8**	**Orch 94-110**
U13	**Twin Electro**	U45	**Smooth Bass**	U77	**Flugel**	U109	**Dark Strings**	**9**	**Drms 111-115**
U14	**Huge FM**	U46	**Acoustic Bass**	U78	**Soprano**	U110	**String Ensemble**	**10**	**Chr-Perc 116-128**
U15	**Elo Piano**	U47	**60 Stopped**	U79	**Tenor**	U111	**Hip Hop Drums**		
U16	**Electro Pad**	U48	**Muted Velo**	U80	**Soft Trombone**	U112	**Pop Drums**		
U17	**Mark**	U49	**Solid Body**	U81	**Latin Flute**	U113	**Chimes**		
U18	**DX Piano**	U50	**Precision Bass**	U82	**Pop Flute**	U114	**Stand Drums 2**		
U19	**EL Piano 1**	U51	**Reso Bass**	U83	**Andes**	U115	**Stand Drums 1**		
U20	**EL Piano 2**	U52	**FInger Bass**	U84	**Voice Flute**	U116	**Bells**		
U21	**Honk Piano**	U53	**Fretless**	U85	**Wow**	U117	**Kalimba**		
U22	**Open Country**	U54	**Slap Bass**	U86	**Poly Synth**	U118	**Etnowood**		
U23	**Golden Steel**	U55	**Synth Bass**	U87	**Trance**	U119	**Karimba**		
U24	**Twin Folk**	U56	**Synth Bass 2**	U88	**Rave**	U120	**VIbraphone**		
U25	**FInger Slide**	U57	**Acoustic Bass**	U89	**Percussive**	U121	**FM Marimba**		
U26	**Nylon Theme**	U58	**Bandoneon**	U90	**Dark B3**	U122	**Toy Box**		
U27	**Finger Guitar**	U59	**Blowing**	U91	**House Synth**	U123	**Mbira**		
U28	**Funky Muted**	U60	**Brass Hits**	U92	**Resonance**	U124	**Steel Pan**		
U29	**Smooth Electric**	U61	**Alpin Muset**	U93	**OBX Poly**	U125	**Marimba**		
U30	**Classical Bright**	U62	**Trombone**	U94	**Muted Trumpet**	U126	**Bright Vibe**		
U31	**Start Folk**	U63	**Horn Pad**	U95	**French Horn**	U127	**Vibrabrato**		
U32	**Nice Guitar**	U64	**Pipe**	U96	**English Horn**	U128	**Chorus Vibes**		

K

Additional PDF Documentation:
https://www.alternatemode.com/altmode-info/documentation/
MalletKAT Online Manual:
https://www.alternatemode.com/online-docs/malletkat/